



Like our products?

Please show your support by writing a product review on the market place where you make your purchase. Even just a quick statement means a lot to us.

Thank you!

iSpringFilter.com



Scan to get your FREE warranty

For questions, comments, or technical support, please contact us at:

✉ support@ispringfilter.com

☎ +1 (678) 261-7611

💬 +1 (470) 560-0012

Monday-Friday 9:00 a.m. - 5:00 p.m. EST


Water's Good®

## iSpring Whole House Filter Replacement Instructions

This instruction works for all iSpring 4.5"-diameter and 20"x 2.5" filter cartridges

### 1. Remove the Old Filter Cartridge

- Turn off the water supply to the system. Open a nearby faucet or water outlet to release the pressure and drain the remaining water from the pipeline and system/housing.
- Use the included housing wrench to remove the filter housing by turning it clockwise. Use a bucket to catch the residual water from the housing.
- Locate and remove the O-ring(s) using a small, clean flat-head screwdriver. Try not to remove any of the lubricants. Set the O-ring(s) aside on a clean and safe surface.
- Lift and remove the filter cartridge from the housing. The housing may still be filled with water. Use the bucket mentioned above to catch the water from the housing. Discard/recycle the used cartridge based on local regulations.




### 2. Sanitize and Prepare the Housing

- Please wear rubber gloves during the whole cleaning process. Wipe the housing and cap with a clean cloth dipped in warm water. Mix the water with about 2 tablespoons of household bleach. Rinse all parts thoroughly after.
- Re-lubricate the O-ring(s) with clean silicone grease if necessary. Do not use petroleum jelly.
- Place the O-ring(s) back to the original position and make sure they are seated correctly.

**Note:** The housing must be properly sealed to prevent leakage. Ensure the O-ring(s) are evenly seated in the groove of the housing. If the O-ring(s) are damaged or crimped, contact iSpring customer service for a replacement or purchase the correct O-ring model: Model#ORB for 4.5"-diameter filter housing, and Model#ORF2 for 20" x 2.5" filter housing.

### 3. Install the New Filter Cartridge

- Remove the new filter cartridge from the packaging and insert it into the housing. If applicable, please follow the directions on the label. Ensure the filter cartridge is seated straight over the standpipe at the bottom of the housing.
- Re-install the filter housing back to the cap. Secure the housing by turning the wrench counterclockwise. Do not overtighten the housing.
- Turn on the water supply, check, and ensure there is no leak from the recently installed housing(s).



### 4. Flushing the System


Turn on the closest faucet and leave the water running for 10-15 minutes or until the water appears clear. This will let fresh water go through the newly installed filter(s) and purge all the loose substances from the filter cartridge.

**Note:** The water may appear cloudy, and small air bubbles may be present for the first few days after installation. This is normal and does not affect water quality.

5. Filter Replacement Schedule:

Filter Type	PP	CTO	GAC	GAC+KDF	Iron / Manganese Removal	Lead Removal CTO	Lead Removal	Anti-scale	PFAS Removal Carbon Fiber	Deionization
Model Series	FP	FC	FG	FG-KS	FM	FC-PB	FCRC	FWDS	FC-PF	FD
Max. Lifespan (month)	6	12	12	12	12	12	12	12	12	12

\*Filter lifespan varies depending on the quality of incoming water and the amount of water consumed daily.



**Note:** All filter cartridges must be replaced periodically. Failure to replace filter cartridges as recommended will void the product warranty and may result in limited performance, damage to the system, and water damage to the property.

WGB12B & WDS Series Replacement Filter Cartridges • Single Stage Filtration				
Filter Type	CTO	Lead Removal CTO	Anti-scale	Anti-scale
Model #	FC25B	FC25B-PB	FWDS150K	FWDS80K
WGB12B	●	○	○	○
WGB12B-CPB	○	●	○	○
WDS150K	○	○	●	○
WDS80K	○	○	○	●

WGB21B & US21B Series Replacement Filter Cartridges (4.5" x 10") • 2-Stage Filtration								
Filter Type	PP	CTO	GAC+KDF	Iron/Manganese Removal	Lead Removal CTO	Lead Removal	Anti-scale	PFAS Removal
Model #	FP15B	FC15B	FG15B-KS	FM15B	FC15B-PB	FCRC15B	FWDS80K	FC15B-PF
WGB21B	●	●	○	○	○	○	○	○
WGB21B-KS	○	●	●	○	○	○	○	○
WGB21BM	○	●	○	●	○	○	○	○
WGB21B-CPB	●	○	○	○	●	○	○	○
WGB21B-PB	○	●	○	○	○	●	○	○
WGB21B-DS	○	●	○	○	○	○	●	○
US21B	○	●	●	○	○	○	○	○
US21B-CPB	○	○	●	○	●	○	○	○
WGB21B-PF	●	○	○	○	○	○	○	●
WGB21B-PFKS	○	○	●	○	○	○	○	●

WGB22B Series Replacement Filter Cartridges (4.5" x 20") • 2-Stage Filtration									
Filter Type	PP	CTO	GAC+KDF	Iron/Manganese Removal	Lead Removal CTO	Lead Removal	Anti-scale	Deionization	PFAS Removal
Model #	FP25B	FC25B	FG25B-KS	FM25B	FC25B-PB	FCRC25B	FWDS150K	FD25B	FC25B-PF
WGB22B	●	●	○	○	○	○	○	○	○
WGB22B-KS	●	○	●	○	○	○	○	○	○
WGB22B-CPB	●	○	○	○	●	○	○	○	○
WGB22BM	○	●	○	●	○	○	○	○	○
WGB22B-PB	○	●	○	○	○	●	○	○	○
WGB22B-DS	○	●	○	○	○	○	●	○	○
WGB22BD	○	○	○	○	○	○	○	●●	○
WGB22BD-BP	○	○	○	○	○	○	○	○	○
WGB22B-PF	●	○	○	○	○	○	○	○	●
WGB22B-PFKS	○	○	●	○	○	○	○	○	●

WGB31B Series Replacement Filter Cartridges (4.5" x 10") • 3-Stage Filtration							
Filter Type	PP	CTO	GAC+KDF	Iron/Manganese Removal	Lead Removal CTO	Anti-scale	PFAS Removal
Model #	FP15B	FC15B	FG15B-KS	FM15B	FC15B-PB	FWDS80K	FC15B-PF
WGB31B	●	●●	○	○	○	○	○
WGB31BM	●	●	○	●	○	○	○
WGB31B-DS	●	●	○	○	○	●	○
WGB31B-KS	●	●	●	○	○	○	○
WGB31B-PF	●	●	○	○	○	○	●
WGB31B-PFKS	●	○	●	○	○	○	●
WGB31B-PFKDS	○	○	●	○	○	●	●
WGB31B-MKS	●	○	●	●	○	○	○
WGB31B-KDS	○	●	●	○	○	●	○
WGB31B-CPB	●	●	○	○	●	○	○

WGB32B Series Replacement Filter Cartridges (4.5" x 20") • 3-Stage Filtration								
Filter Type	PP	CTO	GAC+KDF	Iron/Manganese Removal	Lead Removal CTO	Lead Removal	Anti-scale	PFAS Removal
Model #	FP25B	FC25B	FG25B-KS	FM25B	FC25B-PB	FCRC25B	FWDS150K	FC25B-PF
WGB32B	●	●●	○	○	○	○	○	○
WGB32B-KS	●	●	●	○	○	○	○	○
WGB32BM	●	●	○	●	○	○	○	○
WGB32B-CPB	●	●	○	○	●	○	○	○
WGB32B-PB	●	●	○	○	○	●	○	○
WGB32B-DS	●	●	○	○	○	○	●	○
WGB32B-MKS	●	○	●	●	○	○	○	○
WGB32B-KDS	○	●	●	○	○	○	●	○
WGB32B-PF	●	●	○	○	○	○	○	●
WGB32B-PFKS	●	○	●	○	○	○	○	●
WGB32B-PFKDS	○	○	●	○	○	○	●	●

WCB32 Series Replacement Filter Cartridges (2.5" x 20") • 3-Stage Filtration				
Filter Type	PP	CTO	GAC	GAC+KDF
Model #	FP25	FC25	FG25	FG25-KS
WCB32	●	●●	○	○
WCB32C	●	●●	○	○
WCB32O	●	●	●	○
WCB32C-GAC	●	●	●	○
WCB32C-KS	●	●	○	●

- This filter is the one included in the original system package.
- This filter is compatible with the system but is not included in the original package.



Scan to view the instruction video